

## ASRockind Technical Reference - Q&amp;A

Question	When I turn on the motherboard, we hear 3 beeps sound and monitor has no display. How do I fix it?
Release date	2020/5/1
Product	All model
FAQ type	<input type="checkbox"/> Specification <input type="checkbox"/> OS & Driver <input type="checkbox"/> Application <input type="checkbox"/> BIOS/FW <input checked="" type="checkbox"/> Others

**Answer:**

The system will beep 3 times if it doesn't detect memory correctly.

Please follow the steps below and then check again.

1. Re-install your memory correctly.
2. Only install 1 pcs memory on each DIMM slot to verify.
3. Remove your CPU and check if there's any pin bent on CPU socket.  
(If your system is SoC, please ignore this step.)
4. Please replace another CPU or memory respectively and then check if system can boot up properly.

If you tried the steps above and the symptom still happens, please contact with your local distributor for further assistance.