

## ASRockind Technical Reference - Q&A

<b>Question</b>	The COM port function doesn't work under Linux OS. How do I fix it?
<b>Release date</b>	2020/5/1
<b>Product</b>	Baytrail platform: IMB-150, IMB-151, IMB-152, IMB-153, SBC-210, SBC-211, SBC-212-WT, IMB-1000, IMB-1001.,
<b>FAQ type</b>	<input type="checkbox"/> Specification <input type="checkbox"/> OS & Driver <input checked="" type="checkbox"/> Application <input type="checkbox"/> BIOS/FW <input type="checkbox"/> Others

### **Answer:**

If you would like to use COM port function under Linux OS, please boot into BIOS to set COM Port IRQ Mode to [Linux].

(Path: BIOS > Advanced > Super IO Configuration > COM Port IRQ Mode [Linux])

